




Daily Cappuccinatore/milk frother cleaning

To ensure consistent and high quality milk foam to your customer, the following procedure must be carried out DAILY. For periods of high or sustained usage, it should be carried out MORE frequently.

1. Place the milk suction tube into a container of approx ½ litre of water and suitable cleaning detergent. Ensure it is mixed as directed by its manufacturer
2. Open the steam supply knob and wait for the entire solution to be drawn through automatic milk attachment. Close steam knob.



3. Place the milk suction tube into a container of approx ½ litre of fresh clean tap water.
4. Open steam supply knob again and wait for the entire supply of water to be drawn through the milk frother in order to rinse any detergent residue. Close the steam supply.
5. Finally, inspect the air intake hole (2) for milk residue. If necessary, clear gently with a pin.

If the cappuccinatore attachment becomes blocked or inoperable, remove entirely from the machine by carefully unscrewing. Care MUST be taken due to the hot components.

Remove any milk residue, in particular inside the top of the attachment where it connects to the coffee machine. To refit, simply screw on by hand until tight and orientation is correct