




Time adjustment

Adjusting the time on your LB2200 is a simple procedure.

Throughout the programming procedure, refer to this diagram for button identification:



1. To enter program menu, switch the machine off using the rear switch. Press and hold UP then while still holding UP, simultaneously turn the machine back on.
2. Release UP when the display shows 1: Date and time.
3. Press ENTER twice. Now you should have the current display time with a small '^' cursor under the first digit.
4. Use UP and DOWN to change this to the desired number.
5. Press ENTER to move across to the next digit and again, select using UP and DOWN.
6. After the last digit is set, it is important to press ENTER until the cursor disappears. Only then is then setting remembered.
7. Switch the machine off and on and await 'Ready for use' message.
8. Enjoy a coffee!